



SC100 AI 白板摄像头

Setup Guide | 设置指南



logitech 罗技®

WHAT'S IN THE BOX | 包装内容



EN SC100 AI Camera Units
简体中文 罗技SC100 AI白板摄像头




EN Camera Mounting Bracket
简体中文 摄像头安装支架




EN Mounting Template
简体中文 安装面板




EN Share Button
简体中文 共享按钮



EN Power Injector
简体中文 电源供应器




EN Dongle Transceiver
简体中文 收发器



(2x)

EN CAT5e Cables
简体中文 CAT5E 线缆




(2x)

EN Cable Clips
简体中文 线夹



(4x)

EN Boundary Stickers
简体中文 边界贴纸



EN IEC C8 Power Cord Adapter
简体中文 IEC C8 电源线转接头



(4x)



EN Molly Bolts
简体中文 莫利螺栓




(4x)

EN Wood Screws
简体中文 木螺丝

CAMERA I/O | 摄像头 I/O



CONNECTIONS OVERVIEW | 连接概览




RECOMMENDED CAMERA PLACEMENT HEIGHT

If needed, apply boundary stickers to mark the max capture area.

推荐的摄像头位置高度


如果需要, 请贴上边界贴纸以标记最大捕获区域。



ATTACH THE CAMERA MOUNTING BRACKET

Mark screw hole locations using the mounting template.


1



安装摄像头支架




使用安装面板标记螺丝孔的位置。

2






**PLUG IN THE CAT5E CABLE AND CHOOSE
A ROUTING OPTION**

插入 CAT5E 线缆并选择布线方式




ATTACH THE CAMERA MOUNTING BRACKET

安装摄像头支架




CONNECT THE CAT5E CABLE TO THE POWER INJECTOR

Insert cable connected to camera to "OUT".




将 CAT5E 线缆连接到电源插头


将连接摄像头的线缆插入“输出”。



**CONNECT THE POWER INJECTOR
TO A POWER OUTLET**




将电源插头连接至电源插座




CONNECT SECOND CAT5E CABLE TO THE POWER INJECTOR

Insert cable connected to camera to "IN".




将第二根 CAT5E 线缆连接到电源插头

将连接摄像头的线缆插入“输入”。



**CONNECT THE OTHER END TO THE DONGLE TRANSCEIVER.
PLUG THE DONGLE TRANSCEIVER INTO THE MEETING ROOM PC.**

**将另一端连接至收发器。
将收发器插入会议室 PC。**




RECOMMENDED BUTTON PLACEMENT HEIGHT

Install the button 30"- 48" from the floor.

推荐的按钮位置高度




将按钮安装至距地面 30"- 48" 的高度。



INSTALL SHARE BUTTON



Remove the battery pull tabs only after you have mounted Share Button to the wall.




安装共享按钮



只能在将共享按钮安装于墙面后再移除电池标签。

**START WHITEBOARD SHARING
FROM MEETING ROOM TOUCH CONTROLLER**

使用会议室触摸控制器开始共享白板




CONFIRM CALIBRATION TO FINISH SETUP

If calibration is correct, press the Share button to confirm. If calibration is incorrect, download Logitech Sync to adjust boundaries. logitech.com/sync.



确认校准, 完成设置

如果校正结果正确, 请按下「分享」按钮确认。如果校准不正确, 请下载 Logitech Sync 调整边界。 logitech.com/sync。



CONFIRM CALIBRATION TO FINISH SETUP

If calibration is correct, press the Share button to confirm.

确认校准, 完成设置


如果校准正确, 请按下共享按钮进行确认。

READY TO GO!

Press Share Button to easily start/stop whiteboard sharing into meetings.

开始使用!

按下共享按钮可以轻松启动/停止将白板共享到会议中。



www.logitech.com/support

© 2021 Logitech. Logitech, Logi, 罗技 and the Logitech Logo are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

620-010126 003

版权所有 ©2021 年罗技。罗技、Logi、Logitech 和罗技标志为 罗技欧洲公司 和/或其美国及其他国家/地区附属公司的商标, 并或已注册。所有其它商标均是其各自所有者的财产。罗技对于本手册中可能出现的任何错误不承担任何责任。本手册中包含的信息如有更改, 恕不事先通知。