


RALLY AI CAMERAS EXTENSION KIT


Quick Start Guide



logitech®

RALLY AI CAMERAS - EXTENSION KIT



Wiring Diagram



RALLY AI CAMERAS - EXTENSION KIT

Compatible Cameras




- Rally AI Camera
- Rally AI Camera Pro



RALLY AI CAMERAS - EXTENSION KIT

Required



- Rally AI Camera Pro / Rally AI Camera (including Power Supply & CAT Cable provided)
- Rally AI Cameras Extension Kit
- Room Compute (Rally Bar or PC)
- CAT6A Cable (Installer defined)



RALLY AI CAMERAS - EXTENSION KIT

Device-Side: Step 1




- If installing a White coloured Camera, remove Graphite Decorative Cover, and snap in White Decorative Cover



RALLY AI CAMERAS - EXTENSION KIT

Device-Side: Step 2



- Press Button to remove magnetic Base Plate (keep for later)
- Assemble Device Dongle to base of Camera with 2 x Screws, and Connectors facing as shown



RALLY AI CAMERAS - EXTENSION KIT

Device-Side: Step 3



- Connect short RJ-45 cable to Device Dongle
- While holding short cable in right cable slot, plug the free end into Camera



RALLY AI CAMERAS - EXTENSION KIT

Device-Side: Step 4




- Connect short USB-C cable to Device Dongle
- While holding short cable in middle cable slot, connect the free end into Camera



RALLY AI CAMERAS - EXTENSION KIT

Device-Side: Step 5


- Connect selected CAT6A Cable to Device Dongle, guiding as shown
- Route cable Down, or Up via left cable slot
- Re-assemble magnetic Base Plate to Device Dongle, with Rubber Foot facing Out when standing, or facing In when deployed on Walls or Ceilings



RALLY AI CAMERAS - EXTENSION KIT

Host-side: Step 6









- Connect free end of CAT6A Cable to Host Dongle
- Connect Host Dongle to Room Compute and Power as shown



RALLY AI CAMERAS - EXTENSION KIT

Compatible Mounts

- Rally AI Cameras Wall Box Mount
- Rally AI Cameras Pivot Mount
- Rally AI Cameras Ceiling Standard Mount
- Rally AI Camera Recessed Mount
- Rally AI Camera Pro Recessed mount



RALLY AI CAMERAS EXTENSION KIT

logitech

®